COOPERS

STANDARD WALKING FRAME

Model Nos: 7344C 7345C 7346C 7347C 7321C 7341C 7343C 7331C

7351C 7353C 7323C 7325C 7333C 7335C

7253C 7252C 7254C (Wheels only)

Maximum User Weight: 160kg (25st)

(Do not exceed this weight)

Description of Device and Intended Application:

The Coopers Walking Frame is intended for use by persons with disabilities in or difficulty with walking but who are capable of mobilising themselves. The Coopers Walking Frame can be used indoors or conditionally outdoors

Coopers Walking Frames are personal mobility devices (2 wheeled front legged or 4 ferruled leg types) that are operated manually by the user*

*A user is a disabled person, or a person not having the full capacity to walk unaided

WARNING

For safety, these precautions must be taken when using these products. Before each use make sure:

- · Walker is adjusted to correct height.
- · Locking mechanisms and spring buttons are fully engaged.
- · Walker sits level and all legs are adjusted to correctly.
- Ferrules are in good condition replace if necessary.
- Do not exceed the maximum weight limit for the frame.
- Use only Coopers/Sunrise parts or accessories.
- When using accessories such as bags, baskets etc, ensure these are fitted safely and are not overloaded.
- Stow the frame with care when transporting in a car boot. Damage can occur due to impact with car boot door.

USING THE STANDARD WALKING FRAME

Please read all instructions before use.

PLEASE NOTE:

These are our recommendations but should be checked with your physiotherapist.

When the frame is adjusted correctly the user should be able to maintain an upright posture with the elbow slightly flexed. In this way, body weight is taken through the frame by pushing down on the frame when walking.

COOPERS

STANDARD WALKING FRAME

ADJUSTING THE HEIGHT OF ALL FRAME TYPES


In order to ensure the frame is the correct height for the user, it will need to be adjusted accordingly (your frame will either have a horse shoe clip or spring pin and can be adjusted as shown in Fig 1 or 2).

WARNING: When using a non-wheeled walking frame the legs should be set to the same height. When adjusting frames fitted with wheels it is advisable to set the rear legs one position higher than the front wheels. This is to compensate for the increased height of the wheels at the front which can adversely affect the stability of the frame and the slope of the handles.

Horseshoe Clip Adjustment

- 1. Remove the clip by grasping it between thumb and forefinger and pulling out.
- 2. Slide the leg in or out to the ideal position.
- 3. Push the clip back firmly into the hole.
- 4. Check the clip is fully located before use.
- 5. Repeat for other legs.

FIG. 1



Spring Pin Adjustment

- 1. Press the two buttons in.
- 2. Push the leg as if to shorten.
- 3. Turn the leg slightly.
- 4. Extend the leg to the required position, turn and re-locate buttons into the appropriate holes.
- 5. Check pins are fully located before use.
- 6. Repeat for other legs.



WALKING

- **Step 1.** Stand within the space of the frame.
- Step 2. Place the frame one step ahead
- Step 3. Walk towards it using the affected leg first,
- **Step 4.** Follow with the other leg, which should then step through. **Do not walk too far into the frame area.**

Step 5. When steady, lift the frame and place a short distance in front (When using front wheeled frames, the rear legs should be lifted and wheeled forward as opposed to it being used as a wheeled rollator see Fig 3.) and repeat the process



Note: Coopers wheeled frames have fixed wheels. Where directional realignment of the wheeled frame is required, the frame should be stationary and lifted at the rear in order to turn the frame in the required direction.

USING ALL FRAME TYPES

Walking

- 1. Place the frame one step ahead and walk towards it using the **affected** leg first, followed by the other leg, which should then step through. **Do not walk too far into the frame area**.
- 2. When steady, lift the frame and place a short distance in front (When using front wheeled frames, the rear legs should be lifted and wheeled forward as opposed to it being used as a wheeled rollator.) and repeat this process (Fig 3).

GETTING INTO AND OUT OF CHAIRS

FIG. 3

Getting into and out of Chairs

- 1. Position the frame in front of the chair.
- 2. Get up by pushing on the arms of the chair and transfer hand to frame when fully standing.
- 3. To sit down, using the frame, turn round in front of the chair and feel the chair behind you with your legs.
- 4. Place hands gently on the chair arms, bend slightly forward and sit down gently (Fig 4).





GENERAL SAFETY

- 1. Use a chair with high seat and arms to help you sit and stand up with ease.
- 2. Remove obstacles such as loose rugs, draught excluders and worn floor coverings.
- 3. Ensure lighting in hallways and stairways is adequate.
- 4. Wear flat supportive shoes.
- 5. Avoid wet floors.
- 6. Beware of outdoor hazards including uneven surfaces, wet leaves and ice.
- 7. Do not store this product in temperatures below freezing.
- 8. Take special care if carrying a bag or similar package.
- 9. All equipment should be regularly inspected for any damage or significant signs of wear.

Check regularly for:

- Bent or damaged tubes or cracks at the tube joints.
- Loose or worn horseshoe clips or both buttons of the spring clips are present.
- Loose screws or fasteners.
- · Elongated adjustment holes.
- Loose handles.
- Loose or worn wheels and fasteners (where fitted)
- Smooth, worn or split ferrules (rubber tips).

Replace all worn, missing or damaged parts where necessary.

10. Regular cleaning with a mild disinfectant is recommended. **DO NOT** use bleach or any solvents (such as lighter fluid).



WARRANTY

All Coopers products are warranted for 12 months from the date of purchase against manufacturing or design defects.

The warranty is subject to the following conditions:

- It does not apply to wear and tear, inappropriate or incorrect use, or nonobservance of User Instructions.
- Defective set up by the user or third parties or negligent or careless treatment.
- Use of unsuitable or unapproved spares or unauthorised alteration.
- The warranty does not extend to consequential costs resulting from fault clearance, loss of earnings or expenses

THIS IN NO WAY AFFECTS YOUR STATUTORY RIGHTS.

LIFE EXPECTANCY

We estimate a life expectancy of 2 years for this product, provided that:

- It is used in strict accordance with the intended use as set out in this
 document.
- All service and maintenance requirements are met.

The estimated life expectancy can be exceeded if the product is carefully used and properly maintained.

The life expectancy can also be considerably reduced by extreme or incorrect usage.

The fact that we estimate a life expectancy for this product does not constitute an additional warranty.

COOPERS STANDARD WALKING FRAME Notes.....

